



Start Here



My Verizon

You're now connected to Verizon 4G LTE. Lightning fast, Lightning strong. For more information, visit verizonwireless.com/4GLTE.

REGISTER at verizonwireless.com/myverizon, to learn how to use your phone.

- Go to **My Verizon**
- Click on **Support**
- Click **Device**
- Click on **Select Another Device**

My Verizon allows you to manage your account, pay your bill & more.


Assistance is at your fingertips at verizonwireless.com.

Customer Service is at your disposal at **1-800-922-0204** or at any Verizon Wireless Store.

A comprehensive User Guide is available on demand—simply download one at support.vzw.com/phones or call **1-800-229-1235** to order a copy.

NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.

Phone Features



NOTE: It's important to fully charge battery before turning on your phone.


Non-Removable Battery: Device equipped with internal rechargeable battery. Never attempt to open or disassemble the device yourself, doing so may cause damage that voids your warranty.

Setting Up Your Phone


Installing/Removing the SIM Card*

If not already inserted, follow the instructions below to insert your 4G SIM Card.

1. With the phone facing up, insert the tip of the SIM removal tool into the small hole next to the SIM card tray slot.



2. Push the tip all the way into the hole until the SIM card tray ejects.
3. Pull the SIM card tray out, and place the SIM card (contacts facing down) into the tray.




4. Insert the SIM card tray back into the slot.

NOTE: When removing the SIM card, make sure that you insert the empty SIM card tray back into the slot.

*A Subscriber Identity Module (SIM Card) is a "smartcard" that houses personal information, such as your mobile phone number, calling plan, account information, and content, such as contacts, text messages, and call history. The Verizon Wireless 4G SIM Card is compatible with any Verizon Wireless 4G certified device. You can move the 4G SIM Card from one device to another and your wireless service will work seamlessly as long as you have a compatible device and service plan. To see which devices are compatible with the Verizon Wireless 4G SIM Card, visit verizonwireless.com/certifieddevice.

Charging the Battery

1. Connect the phone to the AC adapter using the USB sync cable.



2. Plug the AC adapter into an electrical outlet to start charging. When charging is complete, the notification LED will change from red to green, and if the phone is on, this icon  displays in the status bar.

Powering On/Off

Press the Power button to turn the phone on.

To turn the phone off, press and hold the Power button until you see **slide down to power off** on the screen. Swipe your finger down the screen.

Setting Up

Follow the on-screen instructions to quickly set up your phone.

For more information visit verizonwireless.com/smartphones. Click **Support** tab, click **Device**, then **Select Another Device** for your device support.

Your Start Screen

The Live Tiles on your Start screen continuously update to show what's most personal to you. You'll see things like your photo album, Xbox LIVE®, how many new messages and emails you have and more.



Lock Screen

Even when your phone is locked, you'll never miss what's happening in your day. You'll get to choose and see notifications right on the lock screen.



To unlock the screen, swipe your finger up on the Lock screen.

To choose what you'd like to see on your lock screen:

1. On the Start screen, flick left.
2. Tap **Settings** > **lock screen**.

Set Up Your Microsoft Account

A Microsoft account is used to sign in to services like Xbox LIVE, the Store, Hotmail®, and so on. Just follow the on-screen instructions during setup and you'll be up and running with your phone in no time.

SkyDrive

Store, access and share Microsoft Office files on SkyDrive. Upload saved files on your phone to SkyDrive for easy accessing from your phone or computer.

Backup AssistantSM Plus

Backup Assistant is now Backup Assistant Plus. Protect your contacts by going to verizonwireless.com/baplus.

Using the Touch Screen

Use touch gestures to move around the screen, open menus, select items, zoom in or out of web pages, and more. You can:

Tap—When you want to type on the keyboard or select on-screen items, just tap them with your finger.

Press and hold—To open the available options for an item, just press and hold the item.

Swipe or slide—Quickly swipe or slide your finger vertically or horizontally across the screen.

Drag—Touch and hold your finger to the screen before you start to drag. While dragging, do not release your finger until you have reached the target position.

Flick—Similar to swiping, except that you need to swipe your finger in light, quicker strokes.

Pinch and spread—In some apps, spread your fingers on the screen to zoom in. Pinch the screen to zoom out.

Making a Call

1. On the Start screen, tap .
2. Tap  to open the keypad.
3. Enter the number you want to call and then tap **call**.

Receiving a Call

When you receive a phone call, the Incoming call screen appears.

- Tap **answer**.
- Or if the display is off and wakes up when you get a call, slide up from the bottom to unlock the screen first and then tap **answer**.

Bluetooth

1. On the Start screen, flick to the left, and then tap **Settings > Bluetooth**.
2. Tap the **On/Off** switch to turn Bluetooth on.
3. Tap the name of the accessory that you want to pair with your phone. When the accessory is connected to your phone, the Bluetooth icon  appears on the status bar.

Set Up Voice Mail

On the Start screen, tap . Dial *86 and tap **call**. If you hear a greeting, press # to interrupt, and follow the setup tutorial.

Access Voice Mail

From your phone—tap . Dial *86 and tap **call**. When you hear the greeting, tap # to interrupt, and follow the prompts.

From any phone—dial your wireless number. When you hear the greeting, press # to interrupt, and follow the prompts.

NOTE: Voice mailboxes not set up within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup tutorial.


Visual Voice Mail

View a list of messages without dialing into a mailbox. Listen or erase with the touch of a button.

To subscribe to Visual Voice Mail, tap  on the Start screen and follow the screen prompts.

Entering Text

When you start an app or select a field that requires text or numbers, the on-screen keyboard becomes available.



After entering your text, press  to close the keyboard. Tap a text field again to show the keyboard.

Live Tiles

Arrange your Start screen how you want it and make it easy to see everything that's going on with the people and passions in your life, real-time. You can size your Live Tiles however you like, making your phone as unique as you are.

Rearranging, Resizing, and Unpinning Tiles

1. Press and hold a tile.
2. To move, drag the tile where you want it to go.
3. To resize, tap the arrow button.
4. To unpin from the Start screen, tap .
5. When you're done moving or resizing tiles, press  or .



Pinning Items to the Start Screen

You can pin just about anything you want to the Start screen: apps, websites, map locations, pictures, songs, shortcuts, and even contacts.

To pin something, let's say a contact, to the Start screen, press and hold it until a menu appears, and then tap **pin to start**.

Ringtones

1. On the Start screen, slide to the left.
2. Tap **Settings > ringtones+sounds**.
3. Tap the **Ringtone** box.
4. Listen to a ringtone by tapping the play icon beside its name.
5. Tap the ringtone you want to use.

Taking and Sharing Photos

1. Press the Camera button on the bottom right side of the phone.
2. Choose your camera settings.
 - Tap  to set the flash.
 - Tap  to switch to the ultra wide angle front camera.
 - Tap  to select or download lenses.
 - Tap **... > photo settings** to choose the resolution you want to use.
3. Hold your phone steady, either vertically or horizontally.
4. Pinch or spread your fingers across the screen to zoom in and out on your subject.
5. Press the Camera button halfway to focus, and then press the button all the way down to take the photo.
6. Tap  **> ... > share**.
7. Select how you want to share the photo.

Apps & More

Play it up with music, apps and games. Keep up with twitter and Facebook. For details and pricing go to **verizonwireless.com**.

Installing Apps

More than one hundred thousand apps are available to download from the Store.

From the Start screen, tap  to access the Store.

Play a Game

Xbox LIVE, the gaming service from Microsoft, lets you play games with your friends and use your gamer profile to keep track of scores and achievements. Through Games Hub, you can do this on your phone.

Note: Xbox LIVE Account required. Visit **support.xbox.com** for details.

BING Search

No matter where you are on the phone, you can always search with Bing by pressing . Just type whatever you're looking for in the search box, then tap  on the on-screen keyboard. Bing will show you not only the web results, but also local results (including maps, ratings, and directions) and images.

Internet Explorer

On the Start screen, tap the **Internet Explorer** tile  to start surfing the web. You can open up to six browser tabs.

Beats by Dr. Dre Audio™

Beats Audio™ integration gives you a rich, authentic sound experience, whether you're listening to music, watching a video, or playing a game. To enjoy Beats Audio, just plug in your headset.

People Hub

Bring your friends, family and colleagues together from multiple social networks into one central place.

Viewing Contacts List and Feeds

Tap the **People** tile on the Start screen.

If you're signed in to your Microsoft account and/or Facebook accounts, swipe to the left to see updates from your friends.

HTC Hub

Check out the weather forecast, stocks and financial market trends, and the latest news around the globe.

Tap the **HTC** hub tile on the Start screen to begin.


NFC

Near Field Communication (NFC) lets you get things done just by tapping your phone on NFC touchpoints—quickly pair compatible Bluetooth accessories, or open a website featured on an advertising poster without typing the web address, and lots more.

Important: Before using NFC, you must enable Bluetooth. NFC on your phone is on by default.

Sharing What's On Your Screen Using NFC

1. Open a photo, contact information, or webpage that you want to share.
2. Tap **... > share** or **share contact** or **share page > Tap+Send**.
3. Place your phone back to back with another phone that has Windows Phone 8 and NFC to start sharing.



Wireless Charging

Charge cable-free. The phone's back cover allows convenient battery charging on a compatible wireless charging mat (sold separately). Contact Verizon Wireless for details and compatibility.

Keeping Things in Sync

It's easy to get your photos, videos, music, documents, and more from your computer to your phone (and vice versa).

If You Have a Windows 8 PC:

Plug your phone into your computer with the cable, and the Windows Phone app will install automatically.

If You Have a Windows 7 PC:

Plug your phone into your computer with the cable. A link will appear to install the Windows Phone app.

If You Have a Mac:

Get the Windows Phone app from the Mac App Store.

Verizon SafeGuards

Family and Safety Apps & Services. Get the most robust parental controls. Go to **verizonwireless.com/safeguards**.

VZ Navigator®

Get premium GPS voice navigations and 3D maps with spoken real-time traffic alerts. Find movie times, event info and gas stations. Go to **verizonwireless.com/navigator**.

Global Ready™

Verizon Wireless keeps you connected around the corner and around the world. For up-to-date information on destinations and rates go to **verizonwireless.com/vzglobal**.

Location Based Services

This phone can determine its location, which is useful for services such as 911, navigation, shopping and weather. Your phone is defaulted to acquire your location.

To use Location Based Services, go to **Settings > location**.

Your wireless device can determine its (and your) physical, geographical location ("Location Information") and can associate Location Information with other data. Additionally, certain applications, services and programs are capable of accessing, collecting, storing and using Location Information and disclosing Location Information to others. You should use caution when determining whether or not Location Information should be made available to others and you should review any applicable third party policies before providing access. To limit potential unauthorized access to your Location Information, Verizon Wireless offers various mechanisms and settings to manage access to location data. By enabling location settings you are permitting third party access to Location Information through software, widgets or peripheral components you choose to download, add or attach to your wireless device or through web access, messaging capabilities or other means and you are authorizing Verizon Wireless to collect, use and disclose your Location Information as appropriate to provide you with any location services that you enabled.

Important Information

Your Wireless Device and Third Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.